

Coherent Signals


98

- Much analysis involves “coherent” signals, i.e. periodic signals whose phase is constant over the relevant duration
 - $Q = \nu/\Delta\nu \gg 1000$
- Examples:
 - Pulses from rotating pulsars;
 - Orbital modulation or eclipses;
 - Precession periods.

Statistics of Power Spectra

99

- How to determine the significance of peaks found in power spectra? How big must a power be to constitute a significant excess over the noise?
- Let's define ε as the probability that a noise fluctuation exceeds P_{det} . The $(1 - \varepsilon)$ confidence detection level P_{det} is a level that has a false alarm probability of ε . If there is just noise, $\text{Prob}(P_j > P_{det}) = \varepsilon$. We want ε to be small, e.g., $\varepsilon = 1\%$ for 99% confidence.
- If $P_j > P_{det}$ then with 99% confidence there is something else than just noise, a source signal.



Statistics of Power Spectra

100

- To determine P_{det} , we need to know **the noise power distribution**.
- **Warning:** Because in High-Energy Astrophysics we are counting individual photons, the relevant statistics are **Poisson**, not **Gaussian**.
- The Leahy normalization is chosen such that if the x_k are **Poisson** distributed, then the P_j exactly follow the **chi-squared distribution** with 2 degrees of freedom, χ^2 . This is actually **an exponential distribution**:

$$\varepsilon = Prob_{single}(P_j > P_{det}) = e^{-P_{det}/2} \longrightarrow P_{det} = -2 \ln \varepsilon$$


- Properties of this distribution: $\langle P_{noise} \rangle = 2$; $Var(P_{noise}) = 4$

Statistics of Power Spectra

101

- Examples:
 - $\varepsilon=1\%$ corresponds to $P_{det}=9.2$;
 - a power of 40 has a probability of $e^{-40/2}=2\times 10^{-9}$ of being noise.
- Since a large number of independent frequencies N_{trial} are examined, the detection threshold has to be defined as that power that has an ε (small) probability to be exceeded in one frequency bin out of the N_{trial} examined.
 - One should divide ε by the number of trials.

$$\varepsilon = N_{trial} e^{-P_{det}/2}$$



Statistics of Power Spectra

102


Important! The number of trial powers N_{trial} over which the search has been carried out:

N_{trial} = to the powers in the PSD if **all the Fourier frequencies** are considered;

$N_{\text{trial}} <$ than the powers in the PSD if a smaller range of frequencies has been considered.

- Examples (cont.): $N_{\text{trial}}=10\ 000$
 - $\epsilon=1\%$ corresponds to $P_{\text{det}}=27.6$;
 - a power of 40 has a probability of $e^{-40/2}=2\times 10^{-5}$ of being noise.

Still significant!!



Rebinning and Averaging


103

- The power spectrum is very noisy. Smoothing methods:
 - Average several power spectra of subsegments of the time series;
 - Average adjacent bins in a power spectrum: rebinning;
 - Windowing is also possible.
- Averaged power distribution:
 - Individual P_j follow the chi-squared distribution with 2 dof.
 - Additive property of χ^2 distribution: sum of M powers is distributed as χ^2_{2M}
- M – the number of the time series, W – Frequency rebinning factor:
 $\langle P_{\text{noise}} \rangle = 2$; $\text{Var}(P_{\text{noise}}) = 4/MW$ (the number of trials decreases)
- **Central limit theorem:**
for large MW the distribution of $\overline{P_{WM}}$ tends to normal (Gaussian), with mean 2 and standard deviation $2/\sqrt{MW}$


Signal Detection

104

M=1,
Noisy PDS



M=10,
A signal is clearly detected



A note about rebinning

105

- **Coherent peak:** narrow power distribution – the longer the observation span, the better. The signal power to decrease by $1/MW$.
Is it worth to average or rebin? No.
 - The signal power decreases faster than the threshold power when averaging/rebinning;
 - If the frequency varies (orbital motion) is even worse as you average signal with noise.
- **Broad peak:** broad power distribution - length of observation not crucial - rebinning helps.

Signal detection optimization

106


- The power spectrum of a sinusoidal signal

$$x_k = A \cos(2\pi\nu_{sine}t_k + \varphi):$$

$$|a_j|^2 \approx \frac{1}{4}A^2N^2 \left(\frac{\sin \pi x}{\pi x} \right)^2$$

where $x = (\nu_{sine} - \nu_j)T$


- The highest power in the signal power spectrum will be obtained at the Fourier frequency ν_j closest to ν_{sine} . Normalized to a power of 1 for $\nu_{sine} = \nu_j$ ($x = 0$), this power varies between 0.405 and 1, with an average value of 0.773



Signal detection optimization

107


- **Implications:** When searching for strictly coherent signals it is important to rely upon the original/maximum Fourier resolution ($1/T$).



Signal detection optimization

108


- Similar reasoning shows that the signal power for a feature with finite width Δv drops proportionally to $1/MW$ when degrading the Fourier resolution. However, as long as feature width exceeds the frequency resolution, $\Delta v > MW/T$, the signal power in each Fourier frequency within the feature remains approx. constant. When $\Delta v < MW/T$ the signal power begins to drop.



Signal detection optimization

109


- **Implications:** The search for QPOs is a three step interactive process.
- Firstly, estimate (roughly) the feature width.
- Secondly, run again a PSD by setting the optimal value of MW equal to $\sim \Delta\nu T$. Two or three iterations are likely needed.
- Finally, use χ^2 hypothesis testing to derive significance of the feature, its centroid and r.m.s.



Measuring narrow features in PSD

110


- **The QPO frequency varies with time (on short timescales).**
- To minimize the pollution of the frequency drift to the measured QPO parameters, PDS must be integrated on the shortest possible timescales
- **Useful tip:** Produce a dynamical PSD
 - Smooth it in time and frequency
 - Restrict the frequency range to where you see the QPO



Power spectrum plots

111


- Multiply the power spectrum by the frequency
- Obtain a vP_v representation
- Useful to see where the power per decade peaks
- Characteristic frequencies are peaks in vP_v



Periodic Non-sinusoidal Signals

112

- Power for Periodic Nonsinusoidal Signals is spread over harmonics of the modulation frequency:
Confidence lower.



Summary: Detecting something in a power spectrum

113

The process of detecting something in a power spectrum against the background of noise has several steps:

- knowledge of the probability distribution of the noise powers;
- knowledge of the interaction between the noise and the signal powers (determination of the signal upper limit);
- The detection level: Number of trials (frequencies and/or sample);
- Specific issues related to the intrinsic source variability (non Poissonian noise);
- Specific issues related to a given instrument/satellite (spurious signals – spacecraft orbit, wobble motion, large data gaps, etc.).